









X J S _ A F ウィンドウシャッター シャッター先付枠 リモコンスリットシャッター-G R 外付型

| | | | | | |
|---|---|--|--|---|---|
| <p>YJS-17211-XA2W</p> | <p>YJS-***11-XA2W</p> | | | <p>オプション 軒天納まり用点検板使用の場合</p> | |
| <p>WB=1,722 HB=1,103</p> | <p>HB=1,103</p> | | | <p>WB=1,722 HB=1,103</p> | |
|  |  | | |  |  |
| <p>YJS-17218-XA2W</p> | <p>YJS-***18-XA2W</p> | | | | |
| <p>WB=1,722 HB=1,803</p> | <p>HB=1,803</p> | | | | |
|  |  | | |  | |
| <p>YJS-172**-XA2W</p> | | | | | |
| <p>WB=1,722</p> | | | | | |
|  | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |